


Install Sheet:

- Mount Module to flat surface in dry location
- Connect Main battery Negative to Pin 1
- Connect Auxiliary battery Negative to Pin 2
- Connect Load Negative to Pin 3
- Connect 10 Amp fast acting fuse between Main battery Positive and Pin 4
- Connect 10 Amp fast acting fuse between Auxiliary battery Positive and Pin 6
- Connect Load Positive to Pin 5

Note: Use wire of 16 AWG size or larger with insulation class for environment

Warning: warranty void if the above noted 10 Amp fuse is not installed.



TITLE	PST-DC-UPS-1212-10A - Install guide		
AUTHOR	Ben		
DATE	9 24 07	SHEET	1 OF 1
REVISION	REV 3		